




Stewart Connector

SS-39300-005 through SS-39300-012 CAT 8.1 Plug Cable Termination Instructions

<div data-bbox="116 310 181 369" style="border: 1px solid black; padding: 2px; font-weight: bold;">01</div>  <p>Components:</p> <ol style="list-style-type: none"> 1. Plug Body 2. Wire Guide 3. Nut (see CT drawing for nut insert details) 	<div data-bbox="1432 310 1497 369" style="border: 1px solid black; padding: 2px; font-weight: bold;">02</div>  <ul style="list-style-type: none"> • Slide the nut onto the cable end with the threaded portion towards the cut end.
<div data-bbox="116 890 181 949" style="border: 1px solid black; padding: 2px; font-weight: bold;">03</div>  <ul style="list-style-type: none"> • Trim jacket approximately 30mm (1.2 inch) and fold braid back over jacket. 	<div data-bbox="1075 1058 1188 1159" style="border: 1px solid black; padding: 2px; font-weight: bold;">04</div>  <ul style="list-style-type: none"> • Arrange pairs and trim length of foils: <ol style="list-style-type: none"> a. Orange & Brown Pairs: 5mm (0.2 inch) b. Blue & Green Pairs: 13mm (0.5 inch) • Ensure foils remain tightly wrapped.
<div data-bbox="116 1411 181 1470" style="border: 1px solid black; padding: 2px; font-weight: bold;">05</div>  <p>W-BR G BR W-G</p> <p>W-O W-BL O BL</p> <ul style="list-style-type: none"> • Install wire pairs into wire guide per the sticker orientation. • Keep gap between foil ends and wire guide openings as small as possible. 	<div data-bbox="1432 1411 1497 1470" style="border: 1px solid black; padding: 2px; font-weight: bold;">06</div>  <ul style="list-style-type: none"> • Press wires into slots, then trim ends flush with edges of wire guide as shown.

Stewart Connector


SS-39300-005 through SS-39300-012 CAT 8.1 Plug Cable Termination Instructions

07


- Gather braid to either side of the wire guide, then wrap it around the region between the jacket and the wire guide as shown.
- Trim the excess braid on the opposite side.

08


- Press the wire guide into the plug body as shown then close the cover to engage with the base housing.

09


- Slide the nut onto the threads and fully tighten.
- The plug body accepts a 14mm wrench and the nut accepts a 13mm wrench.
- Perform any required electrical tests.

10


- To disassemble, remove the nut and pry the cover open with a small flat screwdriver at the location shown.