

Synchronizing Multiple AD9910 1 GSPS Direct Digital Synthesizers

CIRCUIT FUNCTION AND BENEFITS

Synchronization of multiple direct digital synthesizer (DDS) devices allows precise digital tuning control of the phase and amplitude across multiple frequency carriers, which is useful in radar applications and quadrature (I/Q) upconversion for sideband suppression.

The circuit in Figure 1 demonstrates how to synchronize four AD9910 1 GSPS, DDS chips using the AD9520-0, AD9520-1, AD9520-2, AD9520-3, AD9520-4, or AD9520-5 clock generator and the ADCLK846 clock fanout buffer. The result is precise phase alignment between the clock and output signals of four AD9910 devices.




Figure 1. Setup for Synchronization of Multiple AD9910 Devices (Simplified Schematic, All Connections Not Shown)

08514-001

TABLE OF CONTENTS

Circuit Function and Benefits.....	1
Revision History	2
Circuit Description.....	3
Common Variations.....	4
Reference.....	4

REVISION HISTORY

8/2018—Rev. A to Rev. B

Document Title Changed from CN0121 to AN-1580.....Universal Changes to Circuit Function and Benefits Section and Figure 1 ...	1
Changes to Circuit Description Section	3
Changes to Common Variations Section	4

12/2009—Rev. 0 to Rev. A

Changes to Figure 1	1
---------------------------	---

10/2009—Revision 0: Initial Version

CIRCUIT DESCRIPTION

The circuit in Figure 1 was constructed by connecting the respective evaluation boards for the individual devices. Connections were made with matched cable lengths. The first of three basic requirements to synchronize multiple **AD9910** devices is to provide a coincident reference clock (REF_CLK).

The setup uses the **AD9520-0**, **AD9520-1**, **AD9520-2**, **AD9520-3**, **AD9520-4**, or **AD9520-5** as the REF_CLK source for each **AD9910**. The **AD9520-0**, **AD9520-1**, **AD9520-2**, **AD9520-3**, **AD9520-4**, or **AD9520-5** runs off an external crystal and the internal phase-locked loop (PLL). The **AD9520-0**, **AD9520-1**, **AD9520-2**, **AD9520-3**, **AD9520-4**, or **AD9520-5** distributes phase-aligned, 1 GHz REF_CLK signals (positive emitter-coupled logic (PECL) outputs) to all four **EVAL-AD9910** evaluation boards. The **AD9910** provides a complementary metal-oxide semiconductor (CMOS) output clock to the DG2020A data pattern generator for the I/O_UPDATE signal.

The second step to synchronize the **AD9910** devices is to align the rising edge of the SYNC_CLK signals for all four **AD9910** devices. The SYNC_CLK signal provides the reference for a coincident I/O_UPDATE signal. SYNC_CLK signal alignment is accomplished with the internal synchronization capability of the **AD9910**. The **ADCLK846** distributes phase-aligned SYNC_IN \pm signal to all four **AD9910** devices. See the **AD9910** data sheet for more details.

Figure 2 shows all four SYNC_CLK signals with the **AD9910** internal synchronization circuit disabled. Note that the SYNC_CLK signals are not inherently aligned, even when the REF_CLK signals are phase-aligned.

To phase align the rising edges of the SYNC_CLK signals, one **AD9910** is programmed as the master device and the other three are programmed as slave devices. The SYNC_OUT \pm signal of the master device is a low voltage differential signaling (LVDS) signal that is buffered and distributed by the **ADCLK846** to the **EVAL-AD9910**. The SYNC_IN \pm (LVDS) signal must meet the internal setup and hold time requirements of the system clock of each device. To support this timing requirement, the **AD9910** can delay the SYNC_OUT \pm signal of the master **AD9910**. For additional flexibility, the internal SYNC_IN \pm signal path of each **AD9910** can be independently delayed.




Figure 2. SYNC_CLK Signals Not Aligned

In the setup shown in Figure 1, the connections between boards were made using matched cables, making it possible to use the internal default delay values to phase-align the SYNC_CLK signals. Figure 3 shows SYNC_CLK signal phase alignment via the using the synchronization procedure.




Figure 3. SYNC_CLK Signals Aligned

The last requirement to synchronize multiple DDS devices is a coincident I/O_UPDATE signal, which must match the setup and hold times of the SYNC_CLK signals. The I/O_UPDATE signal, as shown in Figure 1, is sent synchronously to the SYNC_CLK pin, which enables control of the DDS outputs.

Figure 4 and Figure 5 show the DDS outputs in phase alignment. The synchronized devices enable predictable phase and/or amplitude adjustment between DDS devices.




Figure 4. Filtered Phase Aligned DDS Outputs




Figure 5. Unfiltered Phase Aligned DDS Outputs

Note that the system clock in Figure 5 was reduced to operation at 100 MHz and the outputs were unfiltered to display each raw DDS output. Figure 5 also illustrates the value of synchronization with each device outputting the same signal.

COMMON VARIATIONS

Analog Devices, Inc., offers a variety of DDS devices, clock distribution chips, and clock buffers to build a DDS-based clock generator. See the [Direct Digital Synthesis](#) page and the [Clock & Timing](#) page on the Analog Devices website for more information.

REFERENCE

[AN-823 Application Note. Direct Digital Synthesizers in Clocking Applications, Time Jitter in Direct Digital Synthesizer-Based Clocking Systems.](#) Analog Devices.

[AN-837 Application Note. DDS-Based Clock Jitter Performance vs. DAC Reconstruction Filter Performance.](#) Analog Devices.

[Kester, Walt. The Data Conversion Handbook.](#) Chapter 6 and Chapter 7. Analog Devices. 2005.

[Kester, Walt. Optimizing Data Converter Interfaces. High Speed System Applications.](#) Analog Devices. 2006.

[Kester, Walt. DACs, DDSs, PLLs, and Clock Distribution. High Speed System Applications.](#) Analog Devices. 2006.

[MT-031 Tutorial. Grounding Data Converters and Solving the Mystery of "AGND" and "DGND".](#) Analog Devices.

[MT-085 Tutorial. Fundamentals of Direct Digital Synthesis \(DDS\).](#) Analog Devices.

[MT-086 Tutorial. Fundamentals of Phase Locked Loops \(PLLs\).](#) Analog Devices.

[MT-101 Tutorial. Decoupling Techniques.](#) Analog Devices.